

Option II

WiFi Configuration

Via Laptop

I 1. Preparation


1.1 Connect DC cable (PV strings) and turn on DC switch to start inverter.

1.2 Power on laptop and switch on WiFi

II 2. Connect WiFi network of inverter

2.1 Search WiFi network and connect "GoodWe-HF".


2.2 Browse website: <http://10.10.100.254>



2.3 Enter User name: "admin", Password: "admin"




V 3.3 Change Password




VI 4. Choose WiFi signal of your own router by "STA Interface Setting"

4.1 Click 'Search' button and choose your own WiFi connection point




III 3. Configure security setting by "AP Interface Setting"

3.1 Change Network name




IV 3.2 Change Security Mode

3.2 Change Security Mode



VII 5. Restart WiFi module by "Device Management"

5.1 Restart WiFi module



6. Reconnect laptop with local router, browse <http://www.goodwe-power.com> to register and create PV station.